



Pant za ALU sustav FEAL 85 Tečaj za ALU sistem FEAL 85




SK
SUPERKLJUČ®
Tel. +385 (0)1 / 5806 341
superkljuc@superkljuc.eu



1


Bušenje otvora u profilu dovratnika

Vrtanje lukenj v profil podboja

**2**





Bušenje otvora u profilu krila vrata


Vrtanje lukenj v profil vratnega krila




3

Dio spojnice za krilo vrata i dovratnik Del tečaja za vratno krilo in podboj





Profil dovratnika
Profil podboja




Profil krila vrata
Profil vratnega krila

5

Montaža dijela spojnice na dovratnik


Montaža dela tečaja na podboj




6

Montaža dijela spojnice na krilo vrata


Montaža dela tečaja na vratno krilo





Bočno podešavanje i podešavanje pritiska

Stranska nastavitvev in nastavitvev pritiska



Lagano otpustite dva stezna vijka na svim spojnicama.
Rahlo odvijte dva vpenjalna vijaka na vseh tečajih.

Podesite bočni položaj i pritisak krila vrata na brtvu.
Nastavite stranski položaj in pritisak vratnega krila na tesnilo.

Ponovno zategnite stezne vijke.
Ponovno privijte vpenjalne vijake.

Podešavanje visine


Nastavitev višine

Lagano otpustite dva stezna vijka na svim spojnicama.

Rahlo odvijte dva vpenjalne vijake na vseh tečajih.

Podesite visinski položaj krila vrata.
Nastavite višinski položaj vratnega krila.

Ponovno zategnite stezne vijke.
Ponovno privijte vpenjalne vijake.



Učvrstite visinski položaj.
Fiksirajte višinski položaj.